



Table of Contents

Chapter	Description	Page No.
1.	QUANTUM UNITY AUTOMATION SERIES SYSTEM	1—1
1.1.1	Safety Integrity Level Compliant	1—1
1.2	Quantum Unity System Drawing	1—2
1.3	Quantum Unity System Drawing	1—3
1.4	Central Processing Unit	1—4
1.4.1.1	434 12A Quantum Controller	1—9
1.4.2	434 12A Controller	1—10
1.4.2.1	434 12U Quantum Controller	1—11
1.4.3	434 12U Controller	1—12
1.4.3.1	534/14A Quantum Controller	1—13
1.4.4	534/14A Controller	1—14
1.4.4.1	534/14B Quantum Controller	1—15
1.4.5	534/14B Controller	1—16
1.4.5.1	534/14U Quantum Controller	1—17
1.4.6	534/14U Controller	1—18
1.4.7	311-10 Quantum Unity Controller	1—19
1.4.8	311-10 Quantum Unity Controller	1—20
1.4.9	651-50 Quantum Unity Controller	1—21
1.4.10	651-50 Quantum Unity Controller	1—22
1.4.11	651-60S Quantum Unity Safety Controller	1—23
1.4.12	651-60S Quantum Unity Safety Controller	1—24
1.4.13	Safety Integrity Level Compliant	1—24
1.4.14	652-60 Quantum Unity Controller	1—25
1.4.15	652-60 Quantum Unity Controller	1—26
1.4.16	671-60 Quantum Unity Controller	1—27
1.4.17	671-60 Quantum Unity Controller	1—28



Table of Contents

Chapter	Description	Page No.
1.4.18	671-60S Quantum Unity Safety Controller	1—29
1.4.19	671-60S Quantum Unity Safety Controller	1—30
1.4.20	Safety Integrity Level Compliant	1—30
1.4.21	672-60 Quantum Unity Controller	1—31
1.4.22	672-60 Quantum Unity Controller	1—32
1.4.23	672-61 Quantum Unity Controller	1—33
1.4.24	672-61 Quantum Unity Controller	1—34
1.5	Quantum Unity Processors.....	1—35
1.5.1	PCMCIA Memory Cards	1—35
1.5.1.1	Battery Replacement	1—35
1.5.2	PCMCIA Memory Extension Cards.....	1—36
1.5.3	Processor Diagnostics.....	1—37
1.5.3.1	Power up Diagnostics.....	1—37
1.5.3.2	Runtime Diagnostics.....	1—37
1.5.4	Processor Stopped Codes.....	1—38
1.6	LED Indicators	1—39
1.7	Run LED Light Error Codes	1—40
1.8	Front Panel Slide Switches.....	1—41
1.8.1	Top Position, ASCII.....	1—41
1.8.2	Middle Position, RTU.....	1—42
1.8.3	Bottom Position, mem	1—42
1.8.4	Front Panel Key Switch	1—43
1.9	Rear Panel Address Switches	1—44
1.10	Modbus Port Cable Pin-Out.....	1—45
1.10.1	Nine (9) to Nine (9) Pin.....	1—45



Table of Contents

Chapter	Description	Page No.
1.10.2	RJ-45 to 9 pin Modbus Connector.....	1—46
1.10.2.1	Cable Adapter Connections.....	1—46
1.10.3	Unity Front Panel	1—47
1.10.3.1	LCD Contrast	1—47
1.10.4	Unity Front Panel Open.....	1—48
1.10.4.1	Using the Keypad.....	1—49
1.10.5	Unity LED Indicator Lights.....	1—50
1.10.5.1	Communication LED	1—50
1.10.5.2	Status LED	1—50
1.11	M340 Processors	1—51
1.12	M340 Communication Ports	1—52
1.12.1	USB Port.....	1—52
1.12.2	Modbus Serial Port.....	1—53
1.12.2.1	RJ-45 to 9 pin Modbus Connector	1—53
1.12.2.2	Cable Adapter Connections	1—53
1.12.2.3	Modbus Port Location.....	1—54
1.12.3	Ethernet Port.....	1—55
1.12.3.1	Ethernet Rotary Switches	1—56
1.12.3.2	Ethernet Rotary Switch Positions	1—57
1.12.4	CANopen Port.....	1—58
1.13	M340 LED Indicators	1—59
1.13.1	Non-blocking Errors	1—59
1.13.2	Non-blocking Errors Linked to Program	1—60
1.13.3	Processor or System Errors.....	1—60
1.13.4	Blocking Errors.....	1—61
1.13.5	P34 1000 and P34 2000 LED Indicators	1—62
1.13.6	P34 2010 LED Indicators	1—62
1.13.7	P34 2020 LED Indicators	1—63



Table of Contents

Chapter	Description	Page No.
1.13.8	P34 2030 LED Indicators.....	1—63
1.13.9	M340 LED Indicator Lights.....	1—64
1.13.10	M340 LED Indicator Lights CANopen.....	1—65
1.13.11	M340 CARDAC LED Indicator Light.....	1—65
1.14	System Addressing.....	1—66
1.14.1.1	Address Relationship.....	1—66
1.14.2	Topological Addressing 800 Series I/O.....	1—66
1.14.2.1	Addressing Example 800 Series I/O.....	1—67
1.14.3	Discrete I/O Bit Addressing.....	1—67
1.14.3.1	Discrete Input Module Bit Addressing.....	1—68
1.14.3.2	Discrete Input Module Word Addressing.....	1—68
1.14.3.3	Discrete Input Module Word Bit Addressing.....	1—68
1.14.3.4	Discrete Output Module Bit Addressing.....	1—69
1.14.3.5	Discrete Output Module Word Addressing.....	1—69
1.14.3.6	Discrete Output Module Word Bit Addressing.....	1—69
1.14.4	I/O Objects.....	1—70
1.14.5	State RAM Memory Usage.....	1—71
1.14.5.1	State RAM Table.....	1—71
1.14.5.2	State RAM Structure.....	1—71
1.14.6	Quantum Memory Usage 256K Memory.....	1—72
1.14.7	Quantum Memory Allocation (768K).....	1—73
1.14.9	Quantum Unity Memory Structure No Module.....	1—74
1.14.10	Quantum Unity Memory Structure with Module.....	1—75
1.15	Processor Internal Operation and Start-Up.....	1—76
1.16	Segment Solve.....	1—77
1.17	Order of Solve.....	1—78
1.18	Quantum Configuration for IEC 61131-3.....	1—79



Table of Contents

Chapter	Description	Page No.
1.18.1	Selecting a Quantum Controller	1—79
1.18.2	IEC Loadables	1—79
1.18.3	Editing Heap Size	1—80
1.18.4	DX Loadables	1—80
1.18.5	EXE Loadables	1—81
1.18.6	Maximizing Memory	1—81
1.18.7	First Versions of IEC	1—84
1.19	Unity Pro Software	1—85
1.19.1	Tag Names	1—85
1.19.2	Variables	1—85
1.19.3	Located Variables	1—86
1.19.4	Unlocated Variables	1—86
1.19.5	Constants	1—86
1.19.6	Direct Addressing	1—86
1.19.7	State RAM	1—87
1.19.8	Sections	1—87
1.19.9	Structured Data Types	1—88
1.20	Function Block Diagram (FBD)	1—89
1.20.1	IEC Ladder Diagram (LD)	1—89
1.20.2	Structured Text (ST)	1—90
1.20.2.1	Operands	1—91
1.20.2.2	Statements	1—91
1.20.2.3	Allocations	1—91
1.20.2.4	Operators	1—92
1.20.2.5	Loop Control in Structured Text (ST)	1—93
1.20.3	984 Ladder Logic (984LL)	1—94
1.20.4	Instruction List (IL)	1—94



Table of Contents

Chapter	Description	Page No.
1.20.5	Sequential Function Chart (SFC).....	1—94
1.21	Concept Converter.....	1—95
1.22	On-Line States DIRECT, EQUAL, MODIFIED and NOT EQUAL.....	1—96
1.22.1	DIRECT	1—96
1.22.2	EQUAL	1—96
1.22.3	MODIFIED	1—96
1.22.4	NOT EQUAL	1—97
1.22.4.1	Ways of Correcting a NOT EQUAL Status.	1—97
1.23	Derived Function Blocks.....	1—98
1.23.1	Modifying DFB's.....	1—98
1.23.1.1	Adding Pins to DFBs.....	1—99
1.23.2	Elementary Function Blocks	1—99
1.23.3	Organizing the Project	1—99
1.23.4	Organizing Multi-User Work.....	1—100
1.23.5	Animation.....	1—100
1.24	Short Cut Keys.....	1—102
1.24.1	Calling up Menu Command Entries.....	1—103
1.24.2	Moving Insertion Marks in the Text	1—103
1.24.3	Deleting Text.....	1—104
1.24.4	Marking Text.....	1—104
1.24.5	Editing Text.....	1—105
1.24.5.1	Rules	1—105
1.24.6	Calling up Menu Command Entries.....	1—106
1.24.7	Moving the Cursor.....	1—106
1.24.8	Scrolling.....	1—107
1.24.9	Edit	1—107
1.24.10	Allocate Variables for FFB	1—108



Table of Contents

Chapter	Description	Page No.
	1.24.11 Change Variables for FFB.....	1—108
	1.24.12 Change Inputs / Outputs.....	1—108
	1.24.13 Keyboard Graphic Editors	1—109
	1.24.13.1 Rules	1—109
	1.24.14 Calling up Menu Command	1—110
	1.24.15 Placing Objects	1—111
	1.24.16 Moving Fields	1—111
	1.24.17 Selecting Objects	1—112
	1.24.18 Move Objects.....	1—112
	1.24.19 Allocate Variables for an FFB.....	1—112
	1.24.20 Change Variables for an FFB	1—113
	1.24.21 Delete Vertical Link	1—113
	1.24.22 Move Mouse with Keys.....	1—113
	1.24.23 Scrolling	1—113
	1.24.24 Creating Objects	1—114
	1.24.25 Creating Links.....	1—114
	1.24.26 Activate Mode	1—114
	1.24.27 LL984 Short Cut Keys.....	1—115
2.	SYSTEM OPTION MODULES	2—1
	2.1.1 Modbus Plus Communications - (DIO)	2—1
	2.1.2 Network Option Module Communications - (NOM)	2—1
	2.2 Distributed I/O Modules, (DIO)	2—2
	2.2.1 Distributed I/O Module AC Voltage (One Channel)	2—2
	2.2.2 Distributed I/O Remote Adapter (Single Channel).....	2—3
	2.2.3 LED Indicators	2—4
	2.2.4 Rear Panel Address Switches	2—5
	2.2.5 Distributed I/O Module Diagnostics	2—6



Table of Contents

Chapter	Description	Page No.
2.2.6	Distributed I/O Module, CRA 212 10	2—6
2.2.7	Distributed I/O Remote Adapter AC (Dual Channel).....	2—7
2.2.8	Distributed I/O Module, CRA 211 20	2—8
2.2.9	Distributed I/O Remote Adapter DC (Single Channel)	2—9
2.2.10	Distributed I/O Module, CRA 212 20	2—10
2.2.11	Distributed I/O Module DC (Dual Channel)	2—11
2.3	Network Option Module (NOM)	2—12
2.3.1	Modbus Plus Network Option Modules, (NOM 21X 00).....	2—12
2.3.2	Modbus Plus NOM 211 00 & NOM 212 00	2—13
2.3.2.1	Diagnostics	2—13
2.3.3	Front Panel Slide Switches.....	2—14
2.3.3.1	Top Position, ASCII	2—15
2.3.3.2	Middle Position, RTU	2—15
2.3.3.3	Bottom Position, mem.....	2—16
2.3.4	Rear Panel Address Switches	2—17
2.3.5	LED Light Indicators	2—18
2.3.5.1	Run LED Light Error Codes.....	2—19
2.3.5.2	Run Light Error Codes	2—20
2.3.6	Fiber Optic Modbus Plus Network Option Module NOM 252	2—21
2.3.7	Fiber Optic Module (NOM 252 00)	2—22
2.3.7.1	Diagnostics	2—23
2.3.8	Front Panel Slide Switch	2—24
2.3.8.1	Top Position, ASCII	2—25
2.3.8.2	Middle Position, RTU	2—25
2.3.8.3	Bottom Position, mem.....	2—26
2.3.8.4	RJ-45 to 9 pin Modbus Connector	2—26
2.3.8.5	Cable Connector Pinouts	2—27
2.3.8.6	BJ45 Cable Assemblies.....	2—27
2.3.9	Rear Panel Address Switches	2—28



Table of Contents

Chapter	Description	Page No.
	2.3.10 LED Light Indicators	2—29
	2.3.11 Fiber Optic Cable Connections	2—30
	2.3.12 Bus Configuration, Mixed Media.....	2—31
	2.3.13 Pure Fiber Optic Modbus Network.....	2—32
	2.3.14 Tree and Star Modbus Plus Network Configurations	2—33
	2.3.14.1 Modbus Plus Star Configuration	2—34
	2.3.15 Self-Healing Ring Modbus Plus Configuration	2—35
	2.4 Communication and Network Option Modules.....	2—36
	2.5 NOE 211 Ethernet TCP/IP Module	2—37
	2.5.1 Default IP Addressing	2—37
	2.5.2 HEX to Decimal Conversion	2—38
	2.5.3 Verify Default IP Address	2—38
	2.6 Network Connection.....	2—39
	2.7 Twisted Pair TCP/IP Module	2—40
	2.8 LED Indicators	2—41
	2.9 Communications Port.....	2—42
	2.9.1 RJ-45 Port Connectors	2—42
	2.10 NOE 251 Ethernet TCP/IP Module	2—43
	2.11 LED Indicators	2—44
	2.12 Communications Ports	2—45
	2.12.1 ST-Style Port Connectors	2—45
	2.13 NOE 311 Twisted Pair SyMax SyNet to Ethernet Module	2—46
	2.14 LED Indicators	2—47
	2.15 NOE 351 Fiber Optic SyMax SyNet to Ethernet Module.....	2—48



Table of Contents

Chapter	Description	Page No.
2.16	LED Indicators	2—49
2.17	NOE 511 Ethernet 10Base T Module	2—50
2.18	LED Indicators	2—51
2.19	NOE 551 Ethernet Fiber Optic Module	2—52
2.20	LED Indicators	2—53
2.21	NOA 611 Interbus-S Communications Module	2—54
2.22	LED Indicators	2—55
2.23	NOE 771 00 Ethernet I/O Scanner 10/100 MB	2—56
2.24	LED Indicators	2—57
2.24.1	Run Light Status Indication	2—58
2.25	NOC 771 00 Ethernet/IP Modbus TCP 10/100 MB	2—59
2.26	LED Indicators	2—60
2.26.1	NOC 771 01 LED Indicators con't	2—61
2.26.2	Ethernet Diagnostic Parameters	2—62
2.26.2.1	General Parameters	2—62
2.26.2.2	Input Parameters	2—62
2.26.2.3	Output Parameters	2—62
2.26.2.4	Error Counter Parameters	2—63
2.27	NOE 771 10 WEB Server Module	2—64
2.28	LED Indicators	2—65
2.28.1	Run Light Status Indication	2—66
2.28.2	Ethernet Module as a Web Server	2—66
2.29	NOE 771 11 WEB Server Module	2—67
2.30	LED Indicators	2—68



Table of Contents

Chapter	Description	Page No.
	2.30.1 Run Light Status Indication	2—69
	2.30.2 Ethernet Module as a Web Server	2—69
	2.31 NWM 100 00 WEB Server Module	2—70
	2.32 LED Indicators	2—71
	2.33 NOL 911 00 LONWorks Interface	2—72
	2.34 LED Indicators	2—73
	2.35 NOL 911 10 LONWorks Interface	2—74
	2.36 LED Indicators	2—75
	2.37 NOL 911 20 LONWorks Interface	2—76
	2.38 LED Indicators	2—77
	2.39 EIA 921 00 AS-i Master Module	2—78
	2.40 LED Indicators	2—79
	2.40.1 Push Buttons and LED’s on Module.....	2—79
	2.41 CRP 811 Profibus-DP Communications Module	2—80
	2.42 LED Indicators	2—81
	2.43 140 HART Communications Module	2—82
	2.44 LED Indicators	2—83
3.	BACKPLANES.....	3—1
	3.1 Backplane Extender	3—2
	3.2 Two Position Back-plane.....	3—3
	3.3 Three Position Back-plane	3—4
	3.4 Four Position Backplane	3—5



Table of Contents

Chapter	Description	Page No.
3.5	Six Position Backplane	3—6
3.6	Ten Position Backplane	3—7
3.7	Sixteen Position Backplane	3—8
3.8	Backplane Mounting Brackets	3—9
3.8.1	Rear Mount Position	3—9
3.8.2	Front Mount Position.....	3—10
3.9	Mounting Space Requirements	3—11
3.9.1	Electrical / Mechanical Information.....	3—11
3.9.2	Space Requirements.....	3—12
3.10	Mounting Quantum Modules.....	3—13
3.11	Removing Quantum Module I/O Terminal Strips	3—14
4.	POWER SUPPLY MODULES.....	4—1
4.1	AC Power Supplies.....	4—2
4.1.1	AC Power Supply Terminations	4—3
4.2	DC Power Supplies.....	4—4
4.2.1	24 Vdc	4—4
4.2.2	24 Vdc Power Supply Terminations	4—5
4.2.3	48 Vdc	4—6
4.2.4	48 Vdc Power Supply Terminations	4—7
4.2.5	125 Vdc	4—8
4.3	LED Indicators	4—9
4.4	Power Supply CPS 111 00	4—10
4.5	Power Supply CPS 114 00	4—11
4.6	Power Supply CPS 114 10	4—12



Table of Contents

Chapter	Description	Page No.
4.7	Power Supply CPS 114 20.....	4—13
4.8	Power Supply CPS 124 00.....	4—14
4.9	Power Supply CPS 124 20.....	4—15
4.10	Power Supply CPS 211 00.....	4—16
4.11	Power Supply CPS 214 00.....	4—17
4.12	Power Supply CPS 224 00.....	4—18
4.13	Power Supply CPS 414 00.....	4—19
4.14	Power Supply CPS 424 00.....	4—20
4.15	Power Supply CPS 511 00.....	4—21
4.16	Power Supply CPS 524 00.....	4—22
5.	REMOTE I/O DROPS / HEADS	5—1
5.1	Remote I/O Drop CRA 931 00	5—1
5.2	Remote I/O Adapter Module (Single Cable)	5—2
5.3	LED Indicators	5—3
5.3.1	Rear Panel Address Switches	5—4
5.4	Remote I/O Drop CRA 931 01	5—5
5.5	Remote I/O Adapter Module (CRA 931 01)	5—6
5.6	LED Indicators	5—7
5.6.1	Rear Panel Address Switches	5—8
5.7	Remote I/O Drop CRA 932 00	5—9
5.8	Remote I/O Adapter Module (Dual Cable)	5—10
5.9	LED Indicators	5—11



Table of Contents

Chapter	Description	Page No.
5.9.1	Blinking Com Act LED Remote I/O Adapter	5—12
5.10	Remote I/O Head CRP 931 00.....	5—13
5.11	Remote I/O Head Module (Single Cable)	5—14
5.12	Remote I/O Head CRP 932 00.....	5—15
5.13	Remote I/O Head Module (Dual Cable).....	5—16
5.14	LED Indicators	5—17
5.14.1	Blinking Com Act LED Remote I/O.....	5—18
5.15	Quantum Unity Remote I/O	5—19
5.16	Remote I/O System Loss Calculations	5—20
5.16.1	Calculation for dB signal loss in the coaxial cable:	5—20
5.16.2	Calculation of dB signal loss through the taps:	5—20
5.16.3	Calculation using Correct Cable to meet System Specifications	5—20
5.17	I/O Topologies	5—21
5.18	CATV Coaxial Cable Recommended Manufactures	5—22
5.18.1	(Up to 15,000ft.).....	5—22
5.18.2	Description	5—22
5.19	RG-11/U Coaxial Cable Recommended Manufactures	5—23
5.19.1	(Up to 8,000ft.).....	5—23
5.20	RG-6/U Coaxial Cable Recommended Manufactures	5—23
5.20.1	(Up to 5,000ft.).....	5—23
5.21	Connectors	5—24
5.21.1	Recommended Line Tap.....	5—24
5.21.2	Recommended Line Splitter	5—24
5.21.3	Recommended Cable Terminator	5—24



Table of Contents

Chapter	Description	Page No.
	5.21.4 Recommended In-Line Terminator.....	5—25
	5.21.5 Recommended RG-6/U Male F Connector	5—25
	5.21.6 Recommended RG-6/U Male BNC Connectors.....	5—25
	5.21.7 Recommended RG-11/U Male F Connector	5—26
	5.21.8 Recommended RG-11/U BNC Connector.....	5—26
	5.22 Recommended Tools	5—26
	5.23 Manufactures Address & Phone	5—27
	5.23.1 Distributors.....	5—27
6.	QUANTUM I/O MODULES.....	6—1
	6.1 LED Indicators	6—2
	6.1.1 32 Point I/O Module LED.....	6—2
	6.1.2 16 Point and Analog I/O Module LED.....	6—3
	6.2 Bi-directional Modules LED	6—4
	6.3 Input Modules, DC Voltage.....	6—5
	6.4 Input Modules, AC Voltage.....	6—5
	6.5 Output Modules, DC Voltage	6—6
	6.6 Output Modules, AC Voltage	6—6
	6.7 Output Relay Modules	6—7
	6.8 Bi-directional I/O Modules	6—7
	6.9 Analog Input Modules	6—8
	6.10 Analog Output Modules	6—9
	6.11 Analog Combination Module.....	6—10
	6.12 Special I/O Modules.....	6—11



Table of Contents

Chapter	Description	Page No.
6.13	140 CHS 110 00 Hot Standby Module.....	6—12
6.14	LED Indicators.....	6—13
6.15	Hot Standby Slide Switches.....	6—14
6.16	System Compatibility.....	6—15
6.17	Fiber Optic Cable Ports	6—16
6.18	TSX Quantum Hot Standby System	6—17
6.18.1	Single Cable, Hot Standby System.....	6—17
6.18.2	Dual Cable, Hot Standby System.....	6—18
6.18.3	Modbus Plus with Hot Standby System.....	6—19
6.19	Error Codes for the Hot Standby Module (CHS 110)	6—20
6.20	140 EHC 105 00 High Speed Counter Module.....	6—21
6.21	LED Indicators.....	6—22
6.22	140 EHC 202 00 High Speed Counter Module.....	6—23
6.23	LED Indicators.....	6—24
6.24	140 ESI 062 00 ASCII Interface Module.....	6—25
6.25	LED Indicators.....	6—26
6.25.1	Front Panel Push Button.....	6—27
6.25.2	Serial Port Connections	6—28
6.26	140 ERT 854 10 Smart Digital Input.....	6—29
6.27	LED Indicators.....	6—30
6.28	140 HLI 340 00 Hi-Speed Interrupt Module.....	6—31
6.29	LED Indicators.....	6—32



Table of Contents

Chapter	Description	Page No.
6.30	Motion Control I/O Modules.....	6—33
6.31	141 MSB 101 00 Motion Control Module	6—34
6.32	LED Indicators	6—35
6.33	Front Panel Connections.....	6—36
6.33.1	Nine (9) to Nine (9) Pin	6—36
6.33.2	Servo Connector.....	6—37
6.33.3	Servo Connector Pin Descriptions	6—38
6.33.4	Rear Panel Switches.....	6—39
6.34	140 MSC 101 00 Motion Control Module	6—40
6.35	LED Indicators	6—41
6.36	Front Panel Connections.....	6—42
6.36.1	Nine (9) to Nine (9) Pin	6—42
6.36.2	Servo Connector.....	6—43
6.36.3	Servo Connector Pin Descriptions	6—44
6.36.4	Rear Panel Switches.....	6—45
6.37	140 MMC 120 00 Motion Control Module	6—46
6.38	LED Indicators	6—47
6.39	141 MMS 425 01 Multi-Axis Motion Module	6—48
6.39.1	Types of Controllers	6—49
6.39.2	Motion Network.....	6—49
6.40	LED Indicators	6—49
7.	PROGRAMMING INSTRUCTIONS.....	7—1
7.1	Boolean Ladder Logic Functions	7—1
7.2	Timers and Counters.....	7—2



Table of Contents

Chapter	Description	Page No.
7.2.1	Timer/Counter Function Block	7—2
7.2.2	Timers	7—3
7.2.2.1	Top Node (Preset)	7—3
7.2.2.2	Bottom Node (Data Storage Location)	7—3
7.2.3	Counters	7—4
7.2.3.1	Top Node (Preset)	7—4
7.2.3.2	Bottom Node (Data Storage Location)	7—4
7.3	Calculate Functions	7—5
7.3.1	The Three Section Function Block	7—5
7.3.2	Addition Function Block	7—6
7.3.2.1	Top Node (A)	7—6
7.3.2.2	Middle Node (B)	7—6
7.3.2.3	Bottom Node (C)	7—6
7.3.3	Subtraction Function Block	7—7
7.3.3.1	Top Node (A)	7—7
7.3.3.2	Middle Node (B)	7—7
7.3.3.3	Bottom Node (C)	7—7
7.3.4	Test or Compare Function	7—8
7.3.4.1	Top Node (A)	7—8
7.3.4.2	Middle Node (B)	7—8
7.3.4.3	Bottom Node (C)	7—8
7.3.5	Multiply Function Block	7—9
7.3.5.1	Top Node (A)	7—9
7.3.5.2	Middle Node (B)	7—9
7.3.5.3	Bottom Node (C & C ⁺)	7—9
7.3.6	Division Function Block	7—10
7.3.6.1	Top Node (A & A ⁺)	7—10
7.3.6.2	Middle Node (B)	7—10
7.3.6.3	Bottom Node (C & C ⁺)	7—10



Table of Contents

Chapter	Description	Page No.
7.4	16 Bit Addition (AD16).....	7—11
	7.4.1.1 Top Node (A).....	7—11
	7.4.1.2 Middle Node (B)	7—11
	7.4.1.3 Bottom Node (C).....	7—11
7.4.2	16 Bit Subtraction (SU16).....	7—12
	7.4.2.1 Top Node (A).....	7—12
	7.4.2.2 Middle Node (B)	7—12
	7.4.2.3 Bottom Node (C).....	7—12
7.4.3	16 Bit Subtraction as a Compare Function	7—13
	7.4.3.1 Top Node (A).....	7—13
	7.4.3.2 Middle Node (B)	7—13
	7.4.3.3 Bottom Node (C).....	7—13
7.4.4	16 Bit Multiply (MU16).....	7—14
	7.4.4.1 Top Node (A).....	7—14
	7.4.4.2 Middle Node (B)	7—14
	7.4.4.3 Bottom Node (C).....	7—14
7.4.5	16 Bit Division (DV16)	7—15
	7.4.5.1 Top Node (A).....	7—15
	7.4.5.2 Middle Node (B)	7—15
	7.4.5.3 Bottom Node (C).....	7—15
7.5	Data Move Functions	7—16
7.6	Summary of Move Functions	7-18
7.6.1	General Function Block Format	7-20
	7.6.1.1 Source	7-20
	7.6.1.2 Destination	7-20
	7.6.1.3 Length.....	7-20
7.6.2	Register to Table.....	7-21
	7.6.2.1 Top Node (Source).....	7-21
	7.6.2.2 Middle Node (Destination)	7-21



Table of Contents

Chapter	Description	Page No.
	7.6.2.3 Bottom Node (Length)	7-21
7.6.3	Table to Register	7-22
	7.6.3.1 Top Node (Source)	7-22
	7.6.3.2 Middle Node (Destination)	7-22
	7.6.3.3 Bottom Node (Length)	7-22
7.6.4	Table to Table	7-23
	7.6.4.1 Top Node (Source)	7-23
	7.6.4.2 Middle Node (Destination)	7-23
	7.6.4.3 Bottom Node (Length)	7-23
7.6.5	Block Move	7-24
	7.6.5.1 Top Node (Source)	7-24
	7.6.5.2 Middle Node (Destination)	7-24
	7.6.5.3 Bottom Node (Length)	7-24
7.6.6	First In	7-25
	7.6.6.1 Top Node (Source)	7-25
	7.6.6.2 Middle Node (Destination)	7-25
	7.6.6.3 Bottom Node (Length)	7-25
7.6.7	First Out	7-26
	7.6.7.1 Top Node (Source)	7-26
	7.6.7.2 Middle Node (Destination)	7-26
	7.6.7.3 Bottom Node (Length)	7-26
7.6.8	Table Search	7-27
	7.6.8.1 Top Node (Source)	7-27
	7.6.8.2 Middle Node (Destination)	7-27
	7.6.8.3 Bottom Node (Length)	7-27
7.6.9	Block to Table	7-28
	7.6.9.1 Top Node (Source)	7-28
	7.6.9.2 Middle Node (Destination)	7-28
	7.6.9.3 Bottom Node (Length)	7-28



Table of Contents

Chapter	Description	Page No.
7.6.10	Table to Block	7-29
	7.6.10.1 Top Node (Source)	7-29
	7.6.10.2 Middle Node (Destination)	7-29
	7.6.10.3 Bottom Node (Length)	7-29
7.6.11	Indirect Block Read	7-30
	7.6.11.1 Top Node (Source)	7-30
	7.6.11.2 Middle Node (Destination)	7-30
	7.6.11.3 Bottom Node (Length)	7-30
7.6.12	Indirect Block Write	7-31
	7.6.12.1 Top Node (Source)	7-31
	7.6.12.2 Middle Node (Destination)	7-31
	7.6.12.3 Bottom Node (Length)	7-31
7.7	STAT Function	7-32
	7.7.1.1 Top Node (Destination)	7-32
	7.7.1.2 Bottom Node (Length)	7-32
7.8	Health (HLTH) Function	7-33
7.8.1	Learn Mode	7-33
7.8.2	Monitor Mode	7-33
7.8.3	Health Function Control	7-34
	7.8.3.1 Top Node (Source)	7-34
	7.8.3.2 Middle Node (Destination)	7-34
	7.8.3.3 Bottom Node (Length)	7-34
7.8.4	Distributed I/O Health (DIOH) Function	7-35
	7.8.4.1 Top Node (Source)	7-35
	7.8.4.2 Middle Node (Destination)	7-35
	7.8.4.3 Bottom Node (Length)	7-35
7.9	Matrix Functions	7-36
7.10	Summary of Matrix Functions	7-38



Table of Contents

Chapter	Description	Page No.
7.10.1	General Function Block Format	7—40
7.10.1.1	Source	7—40
7.10.1.2	Destination	7—40
7.10.1.3	Length	7—40
7.10.2	Sense Bit	7—41
7.10.2.1	Top Node (Source)	7—41
7.10.2.2	Middle Node (Destination)	7—41
7.10.2.3	Bottom Node (Length)	7—41
7.10.3	Modify Bit	7—42
7.10.3.1	Top Node (Source)	7—42
7.10.3.2	Middle Node (Destination)	7—42
7.10.3.3	Bottom Node (Length)	7—42
7.10.4	Bit Rotate	7—43
7.10.4.1	Top Node (Source)	7—43
7.10.4.2	Middle Node (Destination)	7—43
7.10.4.3	Bottom Node (Length)	7—43
7.10.5	Logical AND	7—44
7.10.5.1	Top Node (Source)	7—44
7.10.5.2	Middle Node (Destination)	7—44
7.10.5.3	Bottom Node (Length)	7—44
7.10.6	Logical OR	7—45
7.10.6.1	Top Node (Source)	7—45
7.10.6.2	Middle Node (Destination)	7—45
7.10.6.3	Bottom Node (Length)	7—45
7.10.7	Logical XOR	7—46
7.10.7.1	Top Node (Source)	7—46
7.10.7.2	Middle Node (Destination)	7—46
7.10.7.3	Bottom Node (Length)	7—46



Table of Contents

Chapter	Description	Page No.
7.10.8	Complement.....	7—47
7.10.8.1	Top Node (Source)	7—47
7.10.8.2	Middle Node (Destination)	7—47
7.10.8.3	Bottom Node (Length)	7—47
7.10.9	Bit Matrix Compare	7—48
7.10.9.1	Top Node (Source)	7—48
7.10.9.2	Middle Node (Destination)	7—48
7.10.9.3	Bottom Node (Length)	7—48
7.10.10	Miscellaneous Functions	7—49
7.10.11	Function Block.....	7—50
7.10.11.1	Top Node (Location)	7—50
7.10.11.2	Bottom Node (Bit Number Location)	7—50
7.10.12	Normally Open Bit (NOBT)	7—51
7.10.12.1	Top Node (Location)	7—51
7.10.12.2	Bottom Node (Bit Number Location)	7—51
7.10.13	Normally Closed Bit (NCBT)	7—52
7.10.13.1	Top Node (Location)	7—52
7.10.13.2	Bottom Node (Bit Number Location)	7—52
7.10.14	Normal Bit (NBIT)	7—53
7.10.14.1	Top Node (Location)	7—53
7.10.14.2	Bottom Node (Bit Number Location)	7—53
7.10.15	Set Bit (SBIT)	7—54
7.10.15.1	Top Node (Location)	7—54
7.10.15.2	Bottom Node (Bit Number Location)	7—54
7.10.16	Reset Bit (RBIT)	7—55
7.10.16.1	Top Node (Location)	7—55
7.10.16.2	Bottom Node (Bit Number Location)	7—55



Table of Contents

Chapter	Description	Page No.
7.10.17	Interval Timer Interrupt (ITMR)	7—56
7.10.17.1	Top Node (Location)	7—56
7.10.17.2	Status Register (4XXXX)	7—57
7.10.17.3	Bottom Node (Timer Number)	7—57
7.10.18	Immediate I/O (IMIO)	7—58
7.10.18.1	Top Node (Location)	7—58
7.10.18.2	4XXXX	7—59
7.10.18.3	Bottom Node (I/O Function)	7—59
7.10.19	Block Move with Interrupts Disabled (BMDI)	7—60
7.10.19.1	Top Node (Source)	7—60
7.10.19.2	Middle Node (Destination)	7—60
7.10.19.3	Bottom Node (Length)	7—60
7.10.20	Interrupt Enable (IE)	7—61
7.10.20.1	Single Node	7—61
7.10.21	Interrupt Disable (ID)	7—62
7.10.21.1	Single Node	7—62
7.11	PID Control	7—63
7.12	Proportional Control	7—64
7.13	Proportional-Integral Control	7—65
7.14	Proportional-Integral-Derivative Control	7—66
7.15	The PID Algorithm	7—67
7.16	PID2 Implementation	7—69
7.16.1.1	Top Node (Source)	7—69
7.16.1.2	Middle Node (Destination)	7—69
7.16.1.3	Bottom Node (Length)	7—69
7.17	Top Node Register Usage	7—70
7.18	Middle Node Register Usage	7—75



Table of Contents

Chapter	Description	Page No.
7.19	Bit Zero of Register 4YYY0	7—76
7.20	Error Status Codes	7—77
7.21	Bottom Node Usage	7—79
7.21.1	Top Node Registers	7—80
7.21.2	Middle Node Registers	7—81
7.21.3	Bottom Node Decimal Value	7—81
7.22	PID2 Function Block Outputs	7—82
7.22.1.1	Top Output	7—82
7.22.2	Invalid Parameters:	7—82
7.22.3	Limiting Loops Solved	7—83
7.22.3.1	Top = Parameter Error	7—83
7.22.3.2	Middle = High Alarm on Process Variable	7—83
7.22.3.3	Bottom = Low Alarm on Process Variable	7—83
7.23	PID2 Function Block Inputs	7—84
7.23.1.1	Top Input	7—84
7.23.1.2	Middle Input	7—84
7.23.1.3	Bottom Input	7—84
7.23.2	Mode Selection	7—85
7.23.2.1	Middle Node	7—85
7.24	CHS Hot Standby	7—87
7.24.1.1	Top Input	7—87
7.24.1.2	Middle Input	7—87
7.24.1.3	Bottom Input	7—87
7.24.2	Top Output	7—88
7.24.3	Middle Output	7—88
7.24.4	Bottom Output	7—88
7.24.5	Top Node	7—89



Table of Contents

Chapter	Description	Page No.
7.24.6	Middle Node	7—91
7.24.6.1	Non-Transfer Area	7—92
7.24.7	Bottom Node	7—92
8	WORKSTATION PROBLEMS	8—1
8.1	Determine Analog Values for Levels in a Tank	8—2
8.1.1	Questions:	8—2
8.2	Scaling Analog Values	8—3
8.3	Timer Coil Problem	8—6
8.4	Conveyor Sequence Problem	8—7
8.4.1	Objective:	8—7
8.4.2	Start Sequence Description	8—7
8.4.3	Stop Sequence Description	8—7
8.4.4	System Interrupt Description	8—7
8.4.5	System Hardware	8—8
8.5	Elapsed Timer Problem	8—9
8.5.1	Objective	8—9
8.5.2	Description	8—9
8.5.3	Example	8—9
8.5.4	Hardware	8—10
8.5.5	Example	8—10
8.6	Pipeline, Pump, Tank Problem	8—11
8.6.1	Objective	8—11
8.6.2	Description	8—11
8.6.3	Specifications:	8—11
8.6.4	Pipeline, Pump, Tank Problem Drawing.	8—12



Table of Contents

Chapter	Description	Page No.
	8.7 Move or Word Function Problems	8—13
	8.8 Values 1111 - 1010, Table "A"	8—14
	8.8.1 Objective	8—14
	8.8.2 Description	8—14
	8.8.3 Hardware	8—14
	8.8.4 Table "A"	8—15
	8.9 Scan Times, Table "B"	8—16
	8.9.1 Objective	8—16
	8.9.2 Description	8—16
	8.9.3 Hardware	8—16
	8.9.4 Table "B"	8—16
	8.10 Table "C"	8—17
	8.10.1 Objective	8—17
	8.10.2 Description	8—17
	8.10.3 Hardware	8—17
	8.10.4 Table "C"	8—18
	8.11 Table "D"	8—19
	8.11.1 Objective	8—19
	8.11.2 Hardware	8—19
	8.11.3 Table "D"	8—20
	8.12 Table "E"	8—21
	8.12.1 Objective	8—21
	8.12.2 Description	8—21
	8.12.3 Hardware	8—21
	8.12.4 Table "E"	8—21
	8.13 Table "F"	8—22



Table of Contents

Chapter	Description	Page No.
8.13.1	Objective	8—22
8.13.2	Description	8—22
8.13.3	Hardware.....	8—22
8.13.4	Table "C" to Table "F"	8—23
8.14	Sequence Problem	8—24
8.14.1	Objective	8—24
8.14.2	Description	8—24
8.14.3	Hardware.....	8—24
8.14.4	Table "G".....	8—25
8.14.5	Table "H".....	8—26
8.15	FIN / FOUT, Queue "I"	8—27
8.15.1	Objective	8—27
8.15.2	Description	8—27
8.15.3	Hardware.....	8—27
8.15.4	Queue "I".....	8—28
8.16	Table Search Problem	8—29
8.16.1	Objective	8—29
8.16.2	Description	8—29
8.16.3	Hardware.....	8—29
8.17	Queue "J"	8—30
8.18	Bearing Temperature Monitoring Problem	8—31
8.18.1	Objective	8—31
8.18.2	Description	8—31
8.18.2.1	Normal Temperature Range	8—31
8.18.2.2	Warning Temperature Range.....	8—31
8.18.2.3	Critical Shutdown Temperature Range	8—31



Table of Contents

Chapter	Description	Page No.
8.18.3	Hardware	8—32
8.18.4	Table "K"	8—32
8.19	Time and Date Stamp Problem.....	8—33
8.19.1	Objective	8—33
8.19.2	Description.....	8—33
8.19.3	Table "L"	8—34
8.19.4	Table "M"	8—35
8.20	Batch Process Problem	8—36
8.20.1	Description.....	8—36
8.20.2	Objectives:.....	8—36
8.20.3	Example	8—37
8.20.4	Hardware	8—37
8.21	Warehouse Bar-Code Problem	8—38
8.21.1	Objective	8—38
8.21.2	Description.....	8—38
8.21.3	Four Warehouse Products	8—40
8.21.4	Example:	8—42
8.21.5	MASK.....	8—43
8.21.6	Software	8—44
	Hardware	8—44
8.21.7	Description.....	8—45
8.22	Petro-Chemical Example.....	8—45
8.22.1	Petro-Chemical Products.....	8—46
8.22.2	MASK.....	8—51
8.22.3	Hardware	8—52
8.22.4	Description.....	8—52



Table of Contents

Chapter	Description	Page No.
9.	ETHERNET REMOTE I/O	9—1
9.1.1	Rapid Spanning Tree Protocol	9—1
9.2	Quantum Ethernet I/O Processor	9—2
9.2.1	Ethernet Remote Processor CRP 312 00	9—2
9.2.1.1	CRP 312 00 External Ports	9—3
9.2.1.2	Service Port Configuration	9—3
9.2.1.3	Service Port configuration for Ethernet Adapter Modules	9—4
9.2.1.4	LED Indicators CRP 312 00	9—5
9.2.1.5	CRP 312 00 Ethernet Port Indicators	9—6
9.2.2	Ethernet Remote Adapter CRA 312 00	9—7
9.2.2.1	LED Indicators CRA 312 00	9—8
9.2.2.2	CRA 312 00 Ethernet Port Indicators	9—9
11.	LOADABLE FUNCTION BLOCKS	1
11.1	984 Hot Standby (HSBY)	2
11.1.1	Top Node (Command Register)	2
11.1.2	Middle Node (Non-Transfer Area)	2
11.1.3	Bottom Node (Length)	2
11.1.4	Command Register	3
11.1.5	Middle Node Registers	3
11.1.6	Status Register	4
11.2	Quantum Hot Standby (CHS)	5
11.2.1	Top Node (Command Register)	5
11.2.2	Middle Node (Non-Transfer Area)	5
11.2.3	Bottom Node (Length)	5
11.2.4	Command Register	6
11.2.5	Middle Node Registers	6



Table of Contents

Chapter	Description	Page No.
11.2.6	Status Register	7
11.3	Quantum Hot Standby	8
11.15	Quantum ASCII Module (ESD).....	48
11.15.1	Top Node (Value A)	48
11.15.2	Read ASCII Message	49
11.15.3	Read ASCII Message Response.....	49
11.15.3.1	Module Status	50
11.15.3.2	Status Conditions.....	50
11.15.4	Write ASCII Message	51
11.15.4.1	Write ASCII Response	51
11.15.5	Get Data	52
11.15.5.1	Get Data Response.....	52
11.15.6	Put Data	52
11.15.6.1	Put Data Response.....	53
11.15.7	Abort	53
11.15.7.1	Abort Command Structure	53
11.15.7.2	Abort Response.....	53
11.15.8	Middle Node.....	54
11.15.9	Bottom Node (Length).....	54
11.15.10	Error Codes	55
11.16	Coprocessor Function (CALL).....	56
11.16.1	Top Node (Value A)	56
11.16.2	Middle Node (Value B)	56
11.16.3	Bottom Node (Length).....	56
11.16.4	Immediate DX Functions	57
11.16.5	Deferred DX Functions.....	58
11.17	S975 Modbus II (MBUS)	59



Table of Contents

Chapter	Description	Page No.
11.17.1	Top Node (Value A)	59
11.17.2	Middle Node (Value B)	59
11.17.3	Bottom Node (Length)	59
11.17.4	Top Node Registers	60
11.18	S975 Modbus II (PEER)	61
11.18.1	Top Node (Value A)	61
11.18.2	Middle Node (Value B)	61
11.18.3	Bottom Node (Length)	61
11.18.4	Control Block Registers	62
11.19	Engineering Unit Conversion and Alarm (EUCA)	63
11.20	Implementation	63
11.21	Restrictions	63
11.22	The EUCA Function	64
11.22.1	Top Node (Value A)	64
11.22.2	Alarm Status Block Diagram	66
11.22.3	Middle Node (value B table)	67
11.22.4	Bottom Node (Type)	67
11.22.5	EUCA Inputs	68
11.22.6	EUCA Outputs	68
11.23	The EARS Function	69
11.23.1	Top Node (Value A)	69
11.23.2	Middle Node (Value B)	69
11.23.3	Event Data Register One	70
11.23.4	Event Data Register Two	71
11.23.5	Bottom Node	71
11.24	Custom Loadables	72



Table of Contents

Chapter	Description	Page No.
11.24.1	Top Node (Value A)	72
11.24.2	Middle Node (Value B)	72
11.24.3	Bottom Node (Length)	72
11.25	Drum	73
11.25.1	Top Node (Value A)	73
11.25.2	Middle Node (Value B)	73
11.25.3	Bottom Node (Length)	73
11.25.4	Middle Node Registers	74
11.26	ICMP	75
11.26.1	Top Node (Value A)	75
11.26.2	Middle Node (Value B)	75
11.26.3	Bottom Node (Length)	75
11.26.4	Middle Node Registers	76
11.27	SCIF	77
11.27.1	Top Node (Value A)	77
11.27.2	Middle Node (Value B)	77
11.27.3	Bottom Node (Length)	77
11.27.4	Middle Node Registers	78
12.	QUANTUM UNITY IEC CONFIGURATION	12—1
12.1.1	Sequential Functional Chart	12—2
12.1.2	IEC Ladder Diagram	12—3
12.1.3	984 Ladder Logic	12—4
12.1.4	Instruction List	12—5
12.1.5	Structured Text	12—6
12.1.6	Function Block Diagram	12—7
12.2	Selecting a Quantum Unity Controller	12—8



Table of Contents

Chapter	Description	Page No.
12.2.1	IEC Page Memory	12—8
12.2.1.1	IEC Page Memory	12—9
12.3	Function Block Editor	12—11
12.3.1	Enable On and Enable Off Work	12—12
12.4	Structured Text Editor.....	12—13
12.4.1	Declaring Variables.....	12—13
12.4.2	Next Loop Incrementing through an Array	12—13
12.4.3	Structured Text for Manipulating Equations	12—14
12.4.4	Creating the First DFB.....	12—14
12.4.5	Description of Local and Global DFB	12—15
12.4.6	Project Organization Steps	12—15
12.4.7	Example Application Parameters.....	12—16
12.4.8	Variables.....	12—17
12.4.8.1	Sections.....	12—17
12.4.8.2	Derived Function Blocks.....	12—17
12.4.9	Structured Data Types.....	12—18
12.4.10	Languages.....	12—18
12.4.11	Structured Text Loops	12—18
12.4.12	Memory Partitions	12—20
12.4.13	Memory Statistics	12—20
12.4.14	Memory Size and Memory Map.....	12—20
12.4.15	Optimize Project.....	12—21
12.4.16	PC Configuration.....	12—21
12.4.17	EFB ('C') Tool kit.....	12—21
12.4.18	Animation	12—22



Table of Figures

Figure	Description	Page No.
Figure 1-1	PLC System Drawing.....	1—2
Figure 1-2	Quantum Hot Standby Controller 671-60.....	1—27
Figure 1-3	Quantum Hot Standby Controller 671-60S.....	1—29
Figure 1-4	Quantum Hot Standby Controller 672-60.....	1—31
Figure 1-5	Quantum Hot Standby Controller 672-61.....	1—33
Figure 1-6	Processor LED Panel.....	1—39
Figure 1-7	Processor Control Switches.....	1—41
Figure 1-8	Rear Panel Rotary Address Switches.....	1—44
Figure 1-1-21-9	PC to Unity 9 Pin to RJ-45 Adapter.....	1—46
Figure 1-1-10	PC to Unity 9 Pin Adapter Pin outs.....	1—46
Figure 1-11	Unity LCD Display Panel.....	1—47
Figure 1-12	Unity LCD Display Panel.....	1—48
Figure 1-13	Unity Keypad.....	1—49
Figure 1-14	Unity LED Indicators.....	1—50
Figure 1-15	M340 P34 2020 Processor.....	1—51
Figure 1-16	M340 USB Communications Port.....	1—52
Figure 1-1-17	PC to M340 9 Pin to RJ-45 Adapter.....	1—53
Figure 1-1-18	M340 Ethernet Port.....	1—55
Figure 1-1-19	Rotary Switch Ethernet Port Settings	1—56
Figure 1-20	M340 LED Indicators.....	1—62
Figure 1-218	M340 LED Indicators.....	1—62
Figure 1-34	Rotary Switches.....	1—56



Table of Figures

Figure	Description	Page No.
Figure 1-22	Version 1 LED Indicators	1—63
Figure 1-40	Version 2 LED Indicators	1—63
Figure 1-23	Quantum Unity Memory Structure	1—74
Figure 1-24	Quantum Unity Memory Structure	1—75
Figure 1-25	Quantum Processor I/O Function	1—76
Figure 1-26	Order of Solve	1—77
Figure 1-27	IEC Memory Allocation	1—82
Figure 2-1	Distributed IO Single Channel CRA 211 10	2—3
Figure 2-2	Distributed IO LED Panel	2—4
Figure 2-3	Processor Rotary Switches	2—5
Figure 2-4	Distributed I/O Dual Channel CRA 212 10	2—7
Figure 2-5	Distributed I/O Single Channel CRA 211 20	2—9
Figure 2-6	Distributed I/O Dual Channel CRA 212 20	2—11
Figure 2-7	Dual Channel NOM 212 00	2—13
Figure 2-8	Single Channel NOM 211 00	2—13
Figure 2-9	Slide Switches NOM 212 00	2—14
Figure 2-10	Network Option Module Rotary Switches	2—17
Figure 2-11	Network Option Module LED Panel	2—18
Figure 2-12	Modbus Plus Fiber Optic Module NOM 252 00	2—22
Figure 2-13	Slide Switches NOM 252 00	2—24
Figure 2-14	PC to NOM 252 00 9 Pin to RJ-45 Adapter	2—26
Figure 2-15	PC to NOM 252 00 9 Pin Adapter Pin outs	2—27



Table of Figures

Figure	Description	Page No.
Figure 2-16	NOM Rotary Switches.....	2—28
Figure 2-17	LED Panel NOM 252 00.....	2—29
Figure 2-18	Fiber Optic Cable Connections nom 252 00	2—30
Figure 2-19	Bus Configuration Optic and Copper Network	2—31
Figure 2-20	Bus Configuration Pure Optic Network	2—32
Figure 2-21	Bus Configuration Tree Network	2—33
Figure 2-22	Bus Configuration Star Network.....	2—34
Figure 2-23	Bus Configuration Self -Healing Ring Network	2—35
Figure 2-24	Global Address Conversion (MAC)	2—37
Figure 2-25	HEX to Decimal Calculation.....	2—38
Figure 2-26	NOE 771 10 Network	2—39
Figure 2-27	Ethernet TCP/IP Module 140 NOE 211 00	2—40
Figure 2-28	LED Panel Module 140 NOE 211 00	2—41
Figure 2-29	RJ45 Socket	2—42
Figure 2-30	Ethernet TCP/IP Module 140 NOE 251 00	2—43
Figure 2-31	LED Panel Module 140 NOE 251 00	2—44
Figure 2-32	ST Fiber Optic Connector	2—45
Figure 2-33	10 Base-T Ethernet Module	2—46
Figure 2-34	Quantum to SyMax LED Panel	2—47
Figure 2-35	Quantum SyMax Ethernet	2—48
Figure 2-36	Quantum SyMax Ethernet	2—49



Table of Figures

Figure	Description	Page No.
Figure 2-37	10 Base-T Ethernet.....	2—50
Figure 2-38	Ethernet TCP/IP	2—51
Figure 2-39	Ethernet Fiber Optic	2—52
Figure 2-40	Ethernet Fiber Optic	2—53
Figure 2-41	Interbus S.....	2—54
Figure 2-42	LED Panel Module 140 NOA 611 00	2—55
Figure 2-43	Copper & Fiber Ethernet Module	2—56
Figure 2-44	Ethernet 10/100 MB Copper/100 MB Fiber Optic.....	2—57
Figure 2-45	Ethernet/IP Modbus TCP	2—59
Figure 2-46	LED Indicators NOC 771 01	2—60
Figure 2-47	Copper & Fiber Ethernet Module	2—64
Figure 2-48	Ethernet 10/100 MB Copper/100 MB Fiber Optic.....	2—65
Figure 2-49	Copper & Fiber Ethernet Module	2—67
Figure 2-50	Ethernet 10/100 MB Copper/100 MB Fiber Optic.....	2—68
Figure 2-51	140 NWM 100 00 TCP/IP Modbus Ethernet	2—70
Figure 2-52	Ethernet 10/100 MB Copper/100 MB Fiber Optic.....	2—71
Figure 2-53	LONWorks Module	2—72
Figure 2-54	LON works	2—73
Figure 2-55	LONWorks Module	2—74
Figure 2-56	LONWorks	2—75
Figure 2-57	LONWorks	2—76



Table of Figures

Figure	Description	Page No.
Figure 2-58	LONWorks	2—77
Figure 2-59	AS-i Bus Master Module	2—78
Figure 2-60	AS-I Bus LED Panel.....	2—79
Figure 2-61	CRP 811 00 Profibus Module	2—80
Figure 2-62	Profibus DP.....	2—81
Figure 2-63	HART Module.....	2—82
Figure 2-64	HART Module.....	2—83
Figure 3-1	Backplane Extender	3—2
Figure 3-2	Backplane 2 Slot XBP 002 00	3—3
Figure 3-3	Backplane 3 Slot XBP 003 00	3—4
Figure 3-4	Backplane 4 Slot XBP 004 00	3—5
Figure 3-5	Backplane 6 Slot XBP 006 00	3—6
Figure 3-6	Backplane 10 Slot XBP 010 00	3—7
Figure 3-7	Backplane 16 Slot XBP 016 00	3—8
Figure 3-8	Mounting Bracket 3d Front Mounting	3—9
Figure 3-9	Mounting Bracket 3d Back Mounting	3—10
Figure 3-10	Cabinet Mounting Side View	3—12
Figure 3-11	Inserting Module	3—13
Figure 3-12	Inserting Terminal Strip.....	3—14
Figure 4-1	Power Supply AC Plug	4—2
Figure 4-2	Terminations for CPS 114 20 & CPS 124 20.....	4—3



Table of Figures

Figure	Description	Page No.
Figure 4-3	Terminations for CPS 124 00	4—3
Figure 4-4	Power Supply 24Vdc Terminations.....	4—4
Figure 4-5	Terminations for CPS 214 00 & CPS 224 00	4—5
Figure 4-6	Power Supply 48 to 60 Vdc Terminations	4—6
Figure 4-7	Terminations for CPS 414 00 & CPS 424 00.....	4—7
Figure 4-8	Power Supply 125Vdc Terminations.....	4—8
Figure 4-9	Power Supply LED Panel.....	4—9
Figure 4-10	Power Supply CPS 111 00	4—10
Figure 4-11	Power Supply CPS 114 00	4—11
Figure 4-12	Power Supply CPS 114 10.....	4—12
Figure 4-13	Power Supply CPS 114 20	4—13
Figure 4-14	Power Supply CPS 124 00	4—14
Figure 4-15	Power Supply CPS 124 20.....	4—15
Figure 4-16	Power Supply CPS 211 00	4—16
Figure 4-17	Power Supply CPS 214 00.....	4—17
Figure 4-18	Power Supply CPS 224 00	4—18
Figure 4-19	Power Supply CPS 414 00.....	4—19
Figure 4-20	Power Supply CPS 424 00.....	4—20
Figure 4-21	Power Supply CPS 511 00.....	4—21
Figure 4-22	Power Supply CPS 524 00.....	4—22
Figure 5-1	Remote Processor Single Cable CRA 931 00	5—2



Table of Figures

Figure	Description	Page No.
Figure 5-2	Remote Processor LED Panel	5—3
Figure 5-3	Processor Rotary Switches	5—4
Figure 5-4	Remote Processor Single Cable CRA 931 01	5—6
Figure 5-5	Remote Processor LED Panel	5—7
Figure 5-6	Processor Rotary Switches	5—8
Figure 5-7	Remote Processor Dual Cable CRA 932 00	5—10
Figure 5-8	Remote Adapter LED Panel.....	5—11
Figure 5-9	Remote Processor Head Single Cable CRP 931 00	5—14
Figure 5-10	Remote Processor Head Dual Cable CRP 932 00.....	5—16
Figure 5-11	Remote Processor LED Panel	5—17
Figure 5-12	Remote I/O Cabling	5—19
Figure 5-13	I/O Topologies	5—21
Figure 6-1	I/O Module Exploded View.....	6—1
Figure 6-2	I/O 32 Point LED Panel	6—2
Figure 6-3	I/O 16 Point LED Panel	6—3
Figure 6-4	I/O Bi-Directional LED Panel.....	6—4
Figure 6-5	Hot Standby Module CHS 110.....	6—12
Figure 6-6	Hot Standby Module CHS 110 LED Display	6—13
Figure 6-7	Hot Standby Module Switch Settings	6—14
Figure 6-8	Fiber Optic Cable Connections	6—16
Figure 6-9	Configuration for Hot Standby Single Cable	6—17



Table of Figures

Figure	Description	Page No.
Figure 6-10	Configuration for Hot Standby Dual Cable	6—18
Figure 6-11	Self-Healing Ring for Hot Standby Network.....	6—19
Figure 6-12	High Speed Counter Module ECH 105 00	6—21
Figure 6-13	LED Display ECH 105 00.....	6—22
Figure 6-14	High Speed Counter Module ECH 202 00	6—23
Figure 6-15	LED Display ECH 202 00.....	6—24
Figure 6-16	ASCII Interface Module ESI 062 10	6—25
Figure 6-17	LED Display ESI 062 10	6—26
Figure 6-18	Reset Button ESI 062 10	6—27
Figure 6-19	Serial 9 Pin Connector ESI 062 10	6—28
Figure 6-20	Smart Digital Input Module.....	6—29
Figure 6-21	LED Display ERT 854 10	6—30
Figure 6-22	High Speed Latch Interrupt Module	6—31
Figure 6-23	LED Display HLI 340 00.....	6—32
Figure 6-24	Motion Module MSB 101 00.....	6—34
Figure 6-25	LED Display MSB 101 00.....	6—35
Figure 6-26	Serial 9 Pin to 9 Pin.....	6—36
Figure 6-28	Fifty Pin Connector MSB 101 00	6—37
Figure 6-29	Slide Switch MSB 101 00	6—39
Figure 6-30	Motion Module MSC 101 00.....	6—40
Figure 6-31	LED Display MSC 101 00.....	6—41



Table of Figures

Figure	Description	Page No.
Figure 6-32	Serial 9 Pin to 9 Pin	6—42
Figure 6-34	50 Pin Connector MSC 101 00	6—43
Figure 6-35	Slide Switch MSC 101 00	6—45
Figure 6-36	Motion Module MMC 120 00.....	6—46
Figure 6-37	LED Display MMC 120 00	6—47
Figure 6-38	Quantum SERCOS Multi-Axis Motion Module	6—48
Figure 6-39	Quantum SERCOS Processor LED Panel.....	6—49
Figure 7-1	PID Basic Block Diagram	7—63
Figure 7-2	PID Floating Point Diagram.....	7—63
Figure 8-1	Tank Analog Input Problem	8—2
Figure 8-2	Scaling Raw Analog Data	8—5
Figure 8-3	Timer Coil Problem	8—6
Figure 8-4	Conveyor Sequence Problem.....	8—8
Figure 8-5	Elapse Timer Problem.....	8—9
Figure 8-6	Pipeline - Pump - Tank Problem	8—12
Figure 8-7	Batch Process Tank.....	8—36
Figure 8-8	Barcode Warehouse Problem Conveyor.....	8—38
Figure 8-9	Barcode bit Pattern	8—39
Figure 8-10	Barcode bit Pattern Paper Towels.....	8—40
Figure 8-11	Barcode bit Pattern Hand Towels	8—40
Figure 8-12	Barcode bit Pattern Facial Tissue	8—41



Table of Figures

Figure	Description	Page No.
Figure 8-13	Barcode bit Pattern Toilet Tissue	8—41
Figure 8-14	Barcode Bit Pattern.....	8—42
Figure 8-15	Barcode Bit Pattern Storage Location Mask.....	8—43
Figure 8-16	Barcode bit Pattern Lot Number Mask	8—43
Figure 8-17	Barcode bit Pattern Product Type Mask	8—43
Figure 8-18	Barcode bit Pattern Regular Gas.....	8—46
Figure 8-19	Barcode bit Pattern Unleaded Gas	8—46
Figure 8-20	Barcode bit Pattern Premium Gas.....	8—46
Figure 8-21	Barcode bit Pattern 145 Aviation Fuel.....	8—47
Figure 8-22	Barcode bit Pattern 1 Diesel	8—47
Figure 8-23	Barcode bit Pattern 2 Diesel	8—47
Figure 8-24	Barcode bit Pattern 3 Diesel	8—48
Figure 8-25	Barcode bit Pattern Propane Gas	8—48
Figure 8-26	Barcode bit Pattern LPG Propane	8—48
Figure 8-27	Barcode bit Pattern Kerosene	8—49
Figure 8-28	Barcode bit Pattern 110 Aviation Fuel.....	8—49
Figure 8-29	Barcode bit Pattern	8—50
Figure 8-30	Barcode bit Pattern Storage Location Mask	8—51
Figure 8-31	Barcode bit Pattern Lot Number Mask	8—51
Figure 8-32	Barcode bit Pattern Product Type Mask	8—51
Figure 9-1	Ethernet Remote Processor CRP 312 00	9—2



Table of Figures

Figure	Description	Page No.
Figure 9-2	CRP 312 00 LED Indicators.....	9—5
Figure 9-3	Ethernet Port LED Indicators	9—6
Figure 9-4	CRA 312 00 Ethernet Remote Adapter	9—7
Figure 9-5	CRA 312 00 LED Indicator Lights.....	9—8
Figure 9-6	CRA 312 00 Ethernet Port Indicators	9—9
Figure 11-1	Hot Standby System.....	8
Figure 11-2	Hot Standby Modules CHS 110	9
Figure 11-3	Hot Standby Module CHS 110 LED Display	10
Figure 11-4	Hot Standby Module Switch Settings.....	12
Figure 11-5	Fiber Optic Cable Connections	14
Figure 11-6	Remote Processor LED Panel	15
Figure 11-7	Hot Standby Start Settings	18
Figure 11-8	Primary System Normal LED Lights.....	19
Figure 11-9	Secondary Controller Normal LED Lights.....	20
Figure 11-10	Select Transfer Position	22
Figure 11-11	Push Update Button.....	23
Figure 11-12	Select Position after Transfer	24
Figure 11-13	Release Update Button and Start Transfer	25
Figure 11-14	Transfer Complete View LED Status.....	26
Figure 11-15	Hot Standby with Ethernet Modules.....	27
Figure 11-16	Configuration for Hot Standby Single Cable	33



Table of Figures

Figure	Description	Page No.
Figure 11-17	Configuration for Hot Standby Dual Cable	34
Figure 11-18	Self-Healing Ring for Hot Standby Network.....	35
Figure 11-19	Configuration Extension Size.....	42
Figure 11-20	Select Configuration Extension	43
Figure 11-21	Add an Extension.....	43
Figure 11-22	Hot Standby Extension Select.....	44
Figure 11-23	Configure Registers	44
Figure 11-24	Command Register Configuration	45
Figure 11-25	State RAM Configuration.....	45
Figure 11-26	Ignore Logic Mismatch	46
Figure 11-27	Alarm Status Diagram	66
Figure 12-1	Sample Sequential Functional Chart	12—2
Figure 12-2	IEC Ladder diagram.....	12—3
Figure 12-3	Sample IEC Ladder Diagram.....	12—4
Figure 12-4	Sample Instruction List.....	12—5
Figure 12-5	Structured Text.....	12—6
Figure 12-6	Functional Block Diagram Sample	12—7
Figure 12-17:	Pieces of Memory in a 984-PLC (without IEC).....	12—8
Figure 12-18:	The IEC-Runtime System	12—9
Figure 12-19:	Integrated IEC-System.....	12—10
Figure 12-38:	PID1 Function Block	12—12



Table of Figures

Figure	Description	Page No.
Figure 12-39:	Instruction List.....	12—12